

# Cable Keeper Installation Insert

TS-125, TS-150, TS-200,  
Thermomark 5150/5155/5200/5255,  
AFV, 2411, 2415, and C-Series

Use this insert in conjunction with the installation manual provided with the door.

## INSTALLING CABLE KEEPERS

Cable keepers are now being installed with bottom brackets for doors supplied with 850-11, 400-54, and 5250-54 drums.

Place cable keeper between roller carrier tabs. Insert roller through holes in the tabs and through cable keeper. Rotate arm up and hook around cable, letting cable keeper arm pull against the counter-balance cable, keeping it taut. (see Figure 1)

**NOTE:** Cable keepers are color coded, black for right hand and red for left hand.

**IMPORTANT! CABLE KEEPERS ARE INTENDED TO KEEP CABLES FROM COMING OFF DRUMS ON MANUALLY OPERATED DOORS.**

**⚠ WARNING:** Cable keepers will not prevent cables from coming off drums, if a motor operated door strikes an obstruction on the way down. Cables coming off the drums can allow the door to free-fall, causing severe injury or death.

